



Turn chassis on:

Turn the POWER SWITCH on the front panel clockwise into the ON position and Release. The system will go thru a start up process and it will ask you to press the LOAD button (located on the bottom left of the flat part of the chassis). The system will then ask you to choose MA6 (mask align) or BA6 (bond align) mode by using the Y keys (located in the center of the chassis). You should choose MA6 for mask align mode.

Turn Computer On:

If there is no operating system on the monitor you will need to start the computer (located on the floor to the left of the light power supply). Open the cover on the computer and press the UPS POWER ON button (located at the very bottom of the computer). Next press the square RED button. The computer should boot-up (no pass word required).