



EBeam1 Rotation Fixture Standard Operating Procedure

1. Install Rotation Fixture to front right post, routing the cable across to the front left post, and then down. DO NOT allow the cable to cross over the high voltage feed throughs or damage can occur.



2. Using both hands, plug in the male plug on the cable to the female plug in the chamber. The plug only fits one way.



3. Turn the switch ON to start rotation.



4. When the deposition is complete, Turn the switch off to turn off the rotation.