

Editing a Recipe on Plasma-Therm Versaline DSE

1. Choose the Recipe menu on the bottom of the screen. It is the one with the pencil icon.
2. Choose Edit Recipe screen near the bottom left of the screen.
3. To edit an available recipe Choose the load button on the left side of the screen. A list of available of recipes will be in the middle of the screen.
4. Double click on a recipe.
5. If it is a standard recipe only change the Loop Termination Iterations numbers or time.
6. Choose Save with the Save button on the left side of the screen.
7. To copy, rename, and modify a recipe choose load button on the left side of the screen. Then double click on the recipe that you want to copy.
8. Change recipe name in the Recipe Name bar near the top of the screen first.
9. You can now modify the Process Parameters.
10. Choose Save with the Save button on the left side of the screen.

Delete or Archive a recipe

1. To delete a recipe choose the Archive button
2. Select recipe that you want to delete or archive.
3. Choose Archive button on bottom of the screen.
4. A delete recipe window will pop up and ask. Are you sure?
5. Choose Delete or No.
6. Choose the Done button on the right side of the screen.