

# ICP#1 Wafer Type Change

The system is configured to run 150 mm JEIDA flat wafers but can be temporarily configured to run 150 mm SEMI standard flat wafers as well. If you need to run notched wafers, then you do not need to make any changes.

**IF YOU CHANGE THE CONFIGURATION TO RUN SEMI YOU MUST CHANGE IT BACK TO JEIDA WHEN FINISHED! BE MINDFUL OF THIS WITH YOUR CLEANING RUNS AS OUR CLEANING WAFERS ARE JEIDA!**

1. Press the SYSTEM RESET soft key.
2. Press the MANUAL soft key.
3. Press F10 [TEACH].
4. Press F2 [O.F. TEACH].
5. Press any arrow key on the keyboard to bring up the editing cursor and then enter one of the following values in the O.F. ROTAT. field:
  - JEIDA= 24500
  - SEMI= 25200
6. Press the down arrow key on the keyboard.
7. Press F4 [REGISTER] to save the change and wait for the change registered window to pop up.
8. Press F5 [RETURN] to get back to the main menu.
9. Press the SYSTEM RESET soft key.
10. Press either the AUTO or TEST softkey, depending on what mode you require.

**IF YOU CHANGE THE CONFIGURATION TO RUN SEMI YOU MUST CHANGE IT BACK TO JEIDA WHEN FINISHED! BE MINDFUL OF THIS WITH YOUR CLEANING RUNS AS OUR CLEANING WAFERS ARE JEIDA!**